





# Pellet Durability Index: What Does it Really Measure?

R. W. Rice, University of Maine

Paul Rudnicki, REU Student, University of Notre Dame



#### Purpose




3.1.3 *Pellet Durability Index (PDI)* – a standardized parameter for specifying the ability of the fuel pellets to resist degradation caused by shipping and handling.

Kansas State University - *Mechanical Durability of Feed Pellets, Call Number:* LD2668.T4 1962 Y68

ASAE S269.4: Cubes, Pellets, and Crumbles--Definitions and Methods for Determining Density, Durability, and Moisture Content.



#### Outline of Procedure



$$PDI = \frac{Final\ Pellet\ Weight}{Initial\ Pellet\ Weight} \times 100$$



#### Methods





Common tumble box



Pneumatic, small sample- O NORM M 7135



European Tumbler-EN-15012-1



#### **Tests**



 Duration of tumbling – is 10 minutes really enough to see anything?

Effect of moisture content on durability

Effect of moisture content on pellet strength

Effect of furnish particle size on durability





## Before We Begin: When Does Fracturing and Breakdown Occur?









## Results Fines Generation vs Tumbling Time





#### Pellets After 30 Minutes of Tumbling

Softwood 0% MC (d.b.)

Softwood 13% MC (d.b.)








#### Pure Softwood



#### **Mass Lost As Fines After Durability Test**






#### Pure Hardwood




#### **Mass Lost As Fines After Durability Test**







## Mixed Hardwood/Softwood Blend Mass Lost As Fines After Durability Test








### Results - Mean Length Change



#### Softwood








#### Hardwood











#### Softwood/Hardwood Blend




## Length Distribution After Tumbling







#### **After 20 Minutes**



#### **After 10 Minutes**



#### **After 30 Minutes**



Softwood/Hardwood Blend, 13% MC (d.b.)





### **Compressive Strength Tests**






#### **Instron Compressive Strength Tests**








## Results - Compressive Strength Test







#### What About Particle Size?







#### **Conclusions**



#### **Conclusions**



- Pellet samples of 13% MC (d.b.) show a significant decrease in durability and strength
- Pellet samples of 0% and 6% MC (d.b.) do not show a significant decrease in mean length after 30 minutes in the tumble test
- Pellet furnish size may be important





## Adding water or pre-steaming

- Increases durability
- Decreases energy consumption
- Increases die life





#### Acknowledgements

We gratefully acknowledge the support of the following:

- National Science Foundation, REU Program
- USDA ARS
- USDA McIntyre Stennis Program





#### Thank You.

